

**IN PERC, PETROLEUM  
OR HIGH FLASH  
HYDROCARBON  
SOLVENTS**

**For smoke odors.** Add 1 oz. for every 10 lbs. of load during the final cleaning or rinse cycle.

**To impart a residual  
fragrance effect and to treat  
bacterial and musty odors.**

Add 1/4 oz. (1 capful) for every 10 lbs. of load during the cleaning cycle or last rinse cycle. Adjust the concentration to impart the desired effect. There are many variables that can affect the fragrance effect imparted to textiles. Therefore, use rates can be adjusted to meet individual preferences.

**FOR SPRAY APPLICATIONS  
(CURTAINS/FURNITURE/  
CARPETS)**

Mix 1 part FreshTEX and 8 parts water in a spray bottle or tank and apply as needed. Test hidden area on water sensitive fabrics or dyes.

**FOR LAUNDRY OR  
WETCLEANING USE ON ALL  
ODORS**

Add 1/4 oz. (1 capful) of FreshTEX for every 10 lbs. of load on the final rinse.

**METHOD OF ADDITION**

FreshTEX can be added directly into the button trap, into the wheel (before clothes are added), pumped in via product addition pump or added to a product addition hopper. When any of these methods are chosen it is important to note that FreshTEX should be added to the last bath of solvent or water that the load is exposed to.

---

***How to Order  
FreshTEX***

FreshTEX is sold by authorized Street's distributors and is available in 6 gallon cases and single gallons.

---

*Before using any chemical  
product, review the Material  
Safety Data Sheet (MSDS) for  
safe handling and proper  
disposal.*

*For professional drycleaning and  
laundry use only.*