

Instructions for Using H₂PRO™ Detergent

Use H₂PRO Detergent on water-washable fabrics and hand washables.

Before cleaning garments, remove any solvent-soluble or hard-set stains using the appropriate Street's stain removers. Refer to care label for water temperature.

Hand Washing

1. Use a clean sink or plastic pail. Add 1/4 oz. of H₂PRO Detergent for each gallon of water.
2. Soak lightly soiled fabrics for approximately 15 minutes, gently squeezing the wash water through the fabric periodically. Soak medium to heavily soiled fabrics approximately 30 minutes, squeezing gently periodically.
3. Carefully but thoroughly, squeeze wash water out of fabrics. DO NOT wring fabric.
4. Using another sink or plastic pail, rinse the fabrics with fresh water. Repeat until rinse water is clear.

Top-Loading (Home-Style) Washers

1. Before starting washer, add H₂PRO Detergent based on the appropriate water levels below:
For HIGH water level (full load), add 2 ozs. to 4 ozs. based on the degree of soiling
For MEDIUM water level (medium load), add 1 oz. to 3 ozs. based on the degree of soiling
For LOW water level (small load), add 1/2 oz. to 2 ozs. based on the degree of soiling
2. Add soiled fabrics into the wash wheel and select appropriate setting based on care label, fiber content and construction.

Front-Loading (High-Efficiency) Washers

1. Add H₂PRO Detergent to the detergent dispenser based on the appropriate load levels below:
For FULL load, add 1 oz. to 1-1/4 oz. based on the degree of soiling
For MEDIUM load, add 3/4 oz. to 1 oz. based on the degree of soiling
For SMALL load, add 1/2 oz. to 3/4 oz. based on the degree of soiling
2. Add soiled fabrics into the wash wheel and select appropriate setting based on care label, fiber content and construction.

Professional Laundry or Wetcleaning Machine

1. Add soiled fabrics into the wash wheel and select appropriate setting based on care label, fiber content and construction.
2. Add H₂PRO Detergent at the rate of 1-1/4 oz. to 1-1/2 oz. per 10 gallons of water (refer to machine manual for water equivalents). Alternatively, detergent can be added at a rate of 2-1/2 oz. to 3 oz. per 10 lbs. of garments.

Fabric Finish

For fabrics requiring a soft and supple hand such as cotton sweaters, blankets, golf shirts and woollens, add H₂PRO Fabric Conditioner to the final rinse cycle. For fabrics requiring a firm hand or fabrics which are difficult to press after processing in water such as rayon, linen and cotton, add GELATONE® Fabric Finish to the final rinse. Refer to the product packaging or sales sheet for specific use instructions.

How to Order H₂PRO Detergent

H₂PRO Detergent is sold by authorized Street's distributors everywhere. H₂PRO Detergent is available in single one-gallon containers, cases of four, 5-gallon pails or 15-gallon drums.

Before using any chemical product, review the Safety Data Sheet (SDS) for safe handling and proper disposal.

For professional wetcleaning & laundry use only.

Advancing the Technology of Clean™



©2013
H₂PRO™ & GELATONE® are trademarks of
R. R. Street & Co. Inc., Chicago, IL 60608 (800) 4-STREET or (630) 416-4244
Printed in U.S.A.
#1965 (4/13)